TOP AND CONSOLE PARTS

For Models: LGR7646EQ0, LGR7646EZ0
(Designer White) (Designer Almond)

GAS DRYER



11-96

1	3397545	Panel, Rear Console
2	3354285	Switch, Finish Guard
3	3394427	Clip, Harness
4		Cap, End (L.H.)
	3358528	White
	3358529	Almond
5	3397269	Connector (Timer)
6	688805	Clip
7	3395683	Housing, Connector (Motor)
8		Cap, End (R.H.)
	3358513	White
	3358514	Almond
9	694419	Buzzer, Mini
10	349639	Handle & Lint Screen Assembly
11		Cover, Lint Screen
	688150	White
	689310	Almond
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8-18 x 5/8
14	3397695	Wire, Jumper (Guard/On-Off)
15	693995	Screw, Hex Head
16		Top
	3396022	White
	3396023	Almond
17	3401684	Wire, Jumper (Black)
18	3399639	Switch, Temperature
21	3406048	Timer Assembly (60 Hz.)
22	3403499	Connector, 2-Position (Gas Valve)
23	3403498	Connector, 3-Position (Gas Valve)
29	3390646	Screw, 8-18 x 5/16
30	357213	Nut, Push-In (2)
31	3405125	Harness, Wiring
32	3396029	Wire-Jumper Assembly (Temperature)
39	3398095	Relay, Push-To-Start
40	3401144	Connector (PTS Relay)
48		Timer Knob Assembly
	3396146	White
	3396149	Almond
49		Knob, Push To Start
	3358435	White
	3358436	Almond
50	717252	Receptacle, 2-Way
51	94613	Terminal, Male
52	94614	Terminal, Female
53	3396293	Bracket, Control
54		Panel, Control
	3399053	White
	3399054	Almond
70	353425	Connector (Door Switch)
72	690853	Wire, Ground
76	388326	Screw, Console

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

	LIT3405338	Instructions, Installation

LIT3405515 Use & Care Guide
LIT3401735 Label, Wiring Diagram

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)
72017 White
72107 Almond

PAINT, PRESSURIZED SPRAY (13 oz.)
350930 White
350956 Almond
350938 Primer, Gray

PAINT, BULK (1 qt.)
799344 White (Uncut)
978883 Almond (Uncut)

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS
LIT677818 Dryer

CABINET PARTS

For Models: LGR7646EQ0, LGR7646EZ0
(Designer White) (Designer Almond)



1	697776	Screw, 10-32 x 1/2 (External Ground)
2	343641	Screw, 10-16 x 1/2
3	3404162	Clamp, Motor (W/Shield)
4	238614	Bumper
5	3396795	Cover, Block
6	693995	Screw, Hex Washer Head
7	3396805	Panel, Rear
8	3405101	Harness, Wire (Door Switch)
9	691581	Lever, Door Switch
10	3397503	Switch, Door
11	98129	Screw, 6-20 x 1-3/8
13	694091	Screw, 8-15 x 3/8
14	692495	Spring, Door (2)
15	3357011	Screw, 10-16 x 1/2
16	3392100	Foot, Dryer
	279810	Foot - Optional (Extended Length Package Of 2 (Not Included)
18		Cabinet (Inclues Illus. No's. 5, 7, 16, 29 & 57)
	3399585	White
	3399586	Almond
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21		Panel Front
	3395197	White
	3395198	Almond
23	685203	Clip, Felt Pad (2)
24	3398175	Catch, Door Assembly
25	3390731	Seal, Door
26	337189	Clip, Hinge (2)
27	342043	Screw
28	692498	Hinge, R.H.
	692501	Hinge, L.H.
29	3394083	Clip, Front Panel
33	696144	Strike, Panel
35	695737	Door, Rear
36		Door, Front
	3393549	White
	3393550	Almond
37		Handle, Door
	690270	White
	690271	Almond
38	692493	Seal & Bearing Assembly
45	344020	Cord, Power
49		Plug, Front Panel
	3394975	White
	3394976	Almond
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16-18 x 3/4
59	3401143	Pulley, 60 Hz.
62	3395652	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3401775	Valve, Gas 60 Hz. (Complete)
65	686590	Ignitor
66	3393909	Lock Screw & Washer (8-32 x 5/8)

67	3401771	Burner Assembly, 60 Hz. (See Burner Assembly Parts Page For Further Breakdown)
68	341029	Clamp, Pipe
69	694572	Kit, Conversion Type 1, 2 & 3 To Type 4 (LPG)
70	694539	Coil, 60 HZ. Split (3 Terminal) (Pilot Position)
71	694540	Coil, 60 HZ. (2 Terminal) (Main)
72	694421	Screw, Bracket Mounting (8-32 X 1/2) 2
73	694538	Bracket, Coil
74	694424	Leak Limiter
75	694423	Screw, Regulator Adjustment
76	694422	Spring, Regulator
79	239822	Plug, Pipe

BULKHEAD PARTS

For Models: LGR7646EQ0, LGR7646EZ0
(Designer White) (Designer Almond)



1	348368	Lint Chute Assembly
2	3400800	Screw, 8-18 x 3/4"
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8 x 3/8
6	3404232	Bracket, Drum Light
7	3392519	Fuse, Thermal
8	339554	Screw
9	3387134	Thermostat, Internal-Bias
10	694089	Wheel, Blower (Includes Illus. No. 21)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	685458	Box, Heater
15	3403140	Thermostat, 205~F (96~C)
16	348484	Support, Heater Box
17	348516	Collar, Funnel
18	347389	Funnel, Burner
19	3403634	Socket Assembly
20	851389	Bulb
21	3392123	Seal, Blower
22	3403635	Lens, Drum Light
23	3357011	Screw, 10-12 x 1/2
24	3406022	Bracket, Bulkhead
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403493	Bulkhead
49	338906	Sensor, Radiant
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 7/8
66	347885	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3394133	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust

3401771 BURNER ASSEMBLY

For Models: LGR7646EQ0, LGR7646EZ0
(Designer White) (Designer Almond)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



1	3401771	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	345062	Valve & Union, Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.